

INSTANT QUOTE (IQ)

SMART PRO TOOL

Another Smart Tool from
WarmlyYours Radiant...
What's your IQ?



Instant Quote on the Spot

The WarmlyYours Instant Quote (IQ) Smart Pro Tool, a part of the Radiant Smart Pro Tools collection, puts estimating power directly in your hands, giving you the ability to add a smart, easy-to-use floor heating calculator tool to your own website, without making any major changes. With this, you will reinforce your customers' confidence in purchasing WarmlyYours electric radiant floor heating products from you, while also giving your employees the power to better serve your customers with their floor heating estimates.

Fully Customizable

The IQ is fully customizable. Allowing you to use your company's logo, and your website's branded theme, and is customizable to adjust to your pricing on our radiant heating products. You can even re-name the tool to fit your business. For example, you can name it 'ABC's Floor Heating Instant Quote'.

The best part about it is that it is absolutely **FREE** and now available for you to **use immediately on your own website!** As an added bonus, whenever we upgrade or improve the tool, you will automatically receive the updates without lifting a finger!

Ready for a Demo?

Tell your WarmlyYours representative that you are interested in our **IQ Tool**. And we'll send you an email containing screenshots of how the tool would look on your website. We'll also provide you with a link and instructions on how to use the tool. If you decide to use this tool on your website, we will personally guide you through the quick and easy setup. This tool is just one of many innovations we seek to provide for you, our valued professional.

Your Logo Your Title and Brand Colors

Already know the square footage of the area you would like to warm? Simply enter it below and our calculator will estimate the cost of your floor warming or snow melting project. Keep in mind, floor warming is not installed under permanent fixtures like cabinets.

Application:

Surface Type:

Heating Element Type:

Rectangular Zone

Dimensions of Area To be Heated

Length ft. in. **OR** Square Feet

Width ft. in.

Enter Square Footage to be Warmed:

Square Feet

CALCULATE ▶

How to Calculate the Square Footage to be Warmed

To get started, enter the area that you would like to warm. Remember to exclude the area that is occupied by permanent fixtures or anything that goes through the surface.

Divide the designated area into rectangular zones, as illustrated below. Be sure to use accurate measurements.

For each rectangular zone, enter the length (A) and width (B) in feet and inches as shown in the example below. You can add more zones as required. The total square footage will update as you type.

Then click the "CALCULATE" button and we'll recommend and quote the best set of products to warm your surface.

① A ft. in. X B ft. in.

② A ft. in. X B ft. in.

→ Add Another Zone.

Total sq. ft. of all zones sq. ft.

RESET
CALCULATE


