WarmlyYours
Be Connected.
Be Warm. Be Radiant.

WIRING DIAGRAM
FOR 120V & 240V ENVIRON FLOOR HEATING
USING A JUNCTION BOX WITH DUAL VOLTAGE MYSA

FROM POWER SOURCE 120V & 240V



1. ENSURE THE SYSTEM IS GROUNDED
2. MAT HAS NO POLARITY
3. WIRE FROM THERMOSTAT TO JUNCTION BOX SHOULD BE SIZED ACCORDING TO LOCAL ELECTRICAL CODE REQUIREMENTS.

ELECTRICAL ROUGH-IN